



FOR WORK.  
FOR HOME.  
FOR *everywhere.*



**all makes**

HOME OFFICE  
SOLUTIONS

**COVID-19**  
QUICK RESPONSE



Contact:  
402-341-2413  
info@allmakes.com



# Seating Option 1 –



## TENSION CONTROL

Increase or decrease tension of chair's tilt to match your body weight. Proper tension should allow you to lean back easily while providing balanced support when reclining.

**Pull handle out, turn forward to increase tension and turn handle backwards to reduce tension.**

## PNEUMATIC LIFT

Raise or lower seat of chair to minimize pressure placed under thighs. At the correct seat height, feet should rest flat on the floor.

To ensure smooth operations, raise and lower your seat monthly.

**To raise chair, pull lever up while lifting body off seat.**

**To lower chair, stay seated and pull lever up.**

## ARM HEIGHT\*

Raise or lower arms to support forearms and keep shoulders in a neutral posture.

Proper positioning reduces strain in the neck and shoulders.

**To adjust arm height, press button on outside of arm support while moving arm up or down.**

**Release button to lock in place.**

## TILT LOCK

Locks tilt of chair to limit recline. Back can be locked in an upright position or be set to recline freely.

**Turn handle back to engage lock. Turn handle forward to disengage lock.**

## SEAT SLIDE\*

Adjusts seat depth to a position that best accommodates length of legs. Reduces pressure behind thighs providing long-term comfort.

**With back against chair, push the lever up then slide seat forward or back.**

**Release lever to lock.**

**Option 1 \$299.95 delivered to your residence**

Contact:  
402-341-2413  
info@allmakes.com



**all makes**



# Seating Option 2 –



## SEAT SLIDE\*

Adjusts seat depth to a position that best accommodates length of legs. Reduces pressure behind thighs providing long-term comfort.

**With back against chair, push the lever up and hold, then slide seat forward or back.**

**Release lever to lock.**

## PNEUMATIC LIFT

Raise or lower seat of chair to minimize pressure placed under thighs. At the correct seat height, feet should rest flat on the floor.

To ensure smooth operations, raise and lower your seat monthly.

**To raise chair, pull lever up while lifting body off seat.**

**To lower chair, stay seated and pull lever up.**

## TENSION CONTROL

Increase or decrease tension of chair's tilt to match your body weight. Proper tension should allow you to lean back easily while providing balanced support when reclining.

**Turn knob counter clockwise to increase tension.**

**Turn knob clockwise to reduce tension.**



## ARM HEIGHT\*

Raise or lower arms to support forearms and keep shoulders in a neutral posture.

Proper positioning reduces strain in the neck and shoulders.

**To adjust arm height, press button on outside of arm support while moving arm up or down.**

**Release button to lock in place.**

## TILT LOCK

Locks tilt of chair to limit recline. Back can be locked in an upright position or be set to recline freely.

**Pull lever back to engage lock. Push lever forward to disengage lock.**

**Option 2 \$339 delivered to your residence**

Contact:

402-341-2413

info@allmakes.com



**all makes**



# Desking Option –

- 24" x 60" table
- Metallic Silver Legs
- Five top options to choose from
- Casters are optional
- Height adjustable option is available
- Typically delivery times are 1-5 days from order placement



## TOP COLORS



White  
-WHT



Gray  
-GR



Canvas  
-CNV



Cherry  
-CHE




Chino  
-CHI

\$389 delivered to your residence


Contact:

402-341-2413

[info@allmakes.com](mailto:info@allmakes.com)



all makes



# All orders ship within 48 hours of order entry.

**Contact:**

All Makes

402-341-2413

[info@allmakes.com](mailto:info@allmakes.com)

2558 Farnam Street

Omaha, NE 68131

---

Contact:

402-341-2413

[info@allmakes.com](mailto:info@allmakes.com)



all makes